

Registering your Kindle

Registering your Kindle to your Amazon account lets you shop in the Kindle Store and manage your Kindle content wirelessly from your device.

If your Kindle is already registered with your Amazon account information your Amazon account name (the same one you see when you are shopping on Amazon) will be visible in the top left corner of the Home screen and no further steps are required. However, if you see "My Kindle" instead, you need to register your Kindle.

To register your Kindle:

1. Press the Menu button.
2. Select "Settings," then "register" and follow the instructions. If your Kindle has an existing registration, simply select "Deregister" before entering new account registration information.

If your Amazon user name or password contains characters not present on the Kindle keyboard, press the Symbol (SYM) key to see a menu of characters and numbers and use the 5-way to select the character you require.

You can also manage your device registration through Manage Your Kindle at:
www.amazon.com/manageyourkindle

Manage Your Kindle will also help you set up 1-Click payment method so you can purchase books and other content directly from your Kindle.

You can also watch a video about registering your Kindle and setting up your 1-Click payment method here:

www.amazon.com/help/kindlevideos

Thanks for using Kindle.